

# ingenico

## Move 2500

### User Guide



[www.ingenico.com](http://www.ingenico.com)

13 rue Pagès, 92150 Suresnes – France / (T) +33 (0)1 58 01 80 00

Ingenico - SA au capital de 47 656 332 / 317 218 758 RCS Nanterre



# Contents

<b>1. Introduction</b> .....	<b>4</b>
<b>2. Presentation</b> .....	<b>5</b>
<b>2.1 Content of the box</b> .....	<b>5</b>
<b>2.1.1 Terminal</b> .....	<b>5</b>
<b>2.2 Overview on the MOVE/2500</b> .....	<b>6</b>
<b>2.3 Keyboard details and functionality</b> .....	<b>8</b>
<b>3. Use of the terminal</b> .....	<b>9</b>
<b>3.1 Switching off the terminal</b> .....	<b>9</b>
<b>3.2 Reading card</b> .....	<b>9</b>
<b>4. Installation</b> .....	<b>11</b>
<b>4.1 Recommendation</b> .....	<b>11</b>
<b>4.2 Terminal connections</b> .....	<b>12</b>
<b>4.2.1 uUSB</b> .....	<b>12</b>
<b>4.3 Opening trap door</b> .....	<b>12</b>
<b>4.4 SAMs &amp; SIMs</b> .....	<b>13</b>
<b>4.5 Battery</b> .....	<b>14</b>
<b>4.5.1 Main characteristics</b> .....	<b>14</b>
<b>4.5.2 Installing the battery</b> .....	<b>14</b>
<b>4.5.3 Charging the battery</b> .....	<b>15</b>
<b>4.5.4 Changing the battery</b> .....	<b>16</b>

<b>4.6</b>	Paper roll.....	<b>17</b>
<b>4.6.1</b>	Mains characteristics of INGENICO paper roll.....	<b>17</b>
<b>4.6.2</b>	Installing paper roll.....	<b>18</b>
<b>5.</b>	<b>Recommendations</b> .....	<b>19</b>
<b>5.1</b>	Safety.....	<b>19</b>
<b>5.2</b>	Security of your terminal.....	<b>20</b>
<b>5.3</b>	Fixed installation.....	<b>22</b>
<b>6.</b>	<b>Standards</b> .....	<b>23</b>
<b>6.1</b>	Environment (WEEE, Batteries and Packaging).....	<b>23</b>
<b>6.2</b>	FCC/IC Compliance.....	<b>23</b>
<b>7.</b>	<b>Marking</b> .....	<b>26</b>
<b>8.</b>	<b>Troubleshooting</b> .....	<b>26</b>

# 1.Introduction

We hope that you will be fully satisfied with your new terminal MOVE/2500. This terminal is available in different models. Please select by yourself in this documentation items related to your model.

Read this guide to understand and make the best use of your terminal. It presents you the necessary information about use, installation, maintenance, safety and security recommendations.



## WARRANTY / SECURITY

Use only the power supply included with the product to ensure best performance and safety. Maintenance should only be provided by Ingenico authorized technician. Failure to comply with these instructions will void the manufacturer's responsibility.



This symbol indicates an important Warning.



This symbol indicates a piece of advice.

## 2.Presentation


### 2.1 Content of the box

#### 2.1.1 Terminal


- MOVE/2500 terminal unit equipped with a paper roll



- A battery pack disconnected



- Power adapter



- User guide



#### WARNING

The power supply unit provided with your equipment is specially designed for Ingenico terminals. Do not use any other power supply. The use of a power supply with apparently similar voltage/current characteristics may damage your terminal.



#### ADVICE

Keep the packaging. It must be re-used whenever the terminal is shipped.

## 2.2 Overview of the MOVE/2500



- Terminal unit



● **Compartment where are located:**

- the battery pack
- the SAM/SIM slots



**Weight**  
(without paper roll nor  
battery)

275g

**Dimensions (L x w x h)**

168×81×69 mm

**Electrical mains network**

100-240VAC / 50-60 Hz - Class II  
equipment

**Connections on terminal**

Micro USB AB serial link Power  
connector

## 2.3 Keyboard details and functionality



Some keys can have other functions according to the applications that are in the terminal.



Feed paper a few centimeters if pressed for a long time (more than 2 seconds)

The green key validates input selections and information. It is also used to switch on the terminal

The functions key accesses the different application menus

The red key cancels the procedure in progress

The yellow key cancels the last character



## Smart card

- **Card reader:** insert the card horizontally with the chip facing upwards and leave in position throughout the transaction.



- **Contactless (optional)**

- Bring the card firmly up to the active zone. Keep the card close to the reader during the transaction
- The 4 virtual LEDs are displayed during the transaction.
- The terminal behavior for the cardholder may depend on:
  - The terminal environment
  - Local usage (language...)



## 4. Installation

### 4.1 Recommendations

#### Location of the Move/2500

Place the base on flat surface near an electric socket and according to the base to the telephone or an Ethernet socket. The terminal should be placed far from any very hot zones, protected from vibrations, dust, damp and electromagnetic radiation (computer screen, anti-theft barrier etc.).

#### Operating conditions

Ambient temperature	from +0°C to +50°C
Max relative humidity	85% at +40°C

#### Battery charging conditions

Ambient temperature	from +0°C to +40°C
---------------------	--------------------

#### Storage conditions

Ambient temperature	from -20°C to +55°C
Max relative humidity	85% at +55°C

## 4.2 USB Terminal connections

### 4.2.1 uUSB

- There is an USB connector (MicroAB) on the left side of the Move/2500 Wireless terminal (see below picture). This connector manages Host and Slave connexions.
- The terminal supports USB Keys with FAT16 or FAT32
- The USB Key has to be used with an USB adapter (refers to accessories section)



**USB micro AB**

Connector used for PC travel charger, USB Key, etc...

*\*MicroAB connector durability: up to 10 000 mating cycles*

## 4.3 Opening trap door



### CAUTION

Switch off the terminal before opening the trapdoor.


- Turn the terminal and unclip the trapdoor by pushing on the clip with as shown with the arrows on the picture



## 4.4 SAMs & SIMs

The connector modules security SAM/SIM is located inside the terminal, in a closed compartment.

- SAMs and SIMs are identified by the engraved marks on the lower housing
- When introducing a SAM/SIM in its slot, be sure to put the cut corner as indicated on the engraved marks
- 2 factory options : 1SIM/3SAMs or 2SIMs/2SAMs



## 4.5 Battery

### 4.5.1 Main characteristics

Characteristics	Li-ion 2900 mAh
Charge (power supply-1.5A)	50% capacity in 1,5 h; full capacity in 4 hours (1A)
Battery life	<ul style="list-style-type: none"><li>• 450 transactions in GPRS with fully charged battery, printing and backlit activated</li><li>• Can remain powered ON up to 150 hours with connected GPRS link and terminal in sleeping state starting with fullycharged battery and without energy consumption related to backlit or radio link.</li></ul>

\* The battery capacity depends on the model of terminal and its use

### 4.5.2 Installing the battery




#### WARNING

Check that the terminal is not connected to the main electric network.

- Turn your terminal and unclip the battery trapdoor by pushing on the button as shown on the picture
- Disengage the trapdoor
- Take the battery pack included in the box
- Locate the battery pack connector beside the battery compartment
- Plug the battery pack connector according to the connector locating system and (as shown on picture). Verify that it locks.



- Place the battery pack in its compartment.
- Close the battery compartment trapdoor.



Battery compartment

### 4.5.3 Charging the battery

#### When does the battery need to be charged?

- **On initial start-up**, charge the battery for 16 hours under the environmental conditions stated above
- **When used daily**, the terminal recharges its batteries each time it is placed on its base. Charging is automatic
- **When used with a terminal power supply**: connect the power supply to Move/2500 power connector.

#### How does the battery need to be charged?

- The environment in which the charge takes place influences battery lifetime and autonomy (number of transactions)

The optimal conditions are as follows:

- / Charging away from any external heat source (radiator, sun, enclosed area...)
- / The optimal temperature is between +15°C and +25°C

#### How can the battery be charged?

##### *Using the base*

- Place the terminal on its base
- **Check if the battery symbol is flashing or moving (=battery charging).**

### Using the terminal power supply (the terminal is out of its base)


- Connect the terminal power supply unit to the terminal MicroAB connector located on the left side of the terminal.
- Connect the power supply unit to the power supply mains network
- **Check to see if the battery symbol is flashing or moving(=battery charging)**

## 4.5.4 Changing the battery



It is imperative to use a battery authorized by Ingenico. There is danger of explosion if battery used is not approved by Ingenico.

- Remove the terminal from its base
- Turn it off by pressing simultaneously  d  (low key) for about one second
- Remove the battery trapdoor (see section 4.5.2“installing battery”)
- Lift the battery and remove it from its compartment
- Carefully disconnect battery, following the instructions below.
  - Unlock the connector by pressing the locking mechanism as indicated by F1 arrow while pulling this connector (F2 arrow). Release traction on it as soon as the connector comes unclipped
  - Finish extracting connector by tilting it slightly (F3 arrow) to bring it away from the terminal housing
- Inform the terminal that battery will be replaced (\*). Do so start the terminal without battery by fitting it on its base, or connecting terminal power supply.
- Remove terminal from base or disconnect terminal power supply



- Connect and install the new battery by following the instructions in section 4.5.2 "Installing battery"
- In order to preserve the environment, dispose used battery in compliance with current country recycling legislation.

(\*)The terminal memorizes that there is no battery simply by powering up. It will then correctly perform-full recharge with the next battery.

## 4.6 Paper roll

### 4.6.1 Mains characteristics of INGENICO paper roll

Depending on IWL model two paper roll can be used:

R40 paper roll Characteristics	Precisions
Colour	White
Width	58 mm
Diameter	40 mm
Length	About 18 metres

- The thermal paper can be deteriorated by poor storage conditions, so we recommend you to avoid :
  - / storage in hot wet places (near air-conditioner, humidity higher than 85%)
  - / exposure to sunlight or ultraviolet for long periods
  - / contact with organic solvents (solvent type adhesive)
  - / direct contact with materials containing plasticizers (PVC transparent folders or envelopes)
  - / direct contact with «dialzo» papers
  - / direct contact with water
  - / Rubbing or pressing the paper too strongly



#### WARNING

For best product performance, **only use heat sensitized paper approved by Ingenico.**




### WARNING

Switch off the terminal prior to installing a paper roll.  
Use only paper approved by Ingenico.  
The use of non approved paper is likely to damage the printer of your terminal.

## 4.6.2 Installing paper roll

- Open the paper compartment by lifting the catch located at the rear of the terminal and pull the cover to the rear of the terminal.



- Insert the paper roll in the compartment following the directions shown on the below picture
- Pull the paper up to the top of the terminal
- Maintain the paper and close the lid
- Press simultaneously on both upper corners of the paper flap, as shown by arrows on picture, until it clips into position





### ADVICE

If you insert a new R40 paper roll, tear off the first length (one complete turn to avoid printing on adhesive tape footprint).

## 5. Recommendations

### 5.1 Safety

#### Powering down the Move/3500 :

Disconnect the Move/2500 power supply block adapter from the electrical mains network.

#### Lithium cell

The Move/2500 is fitted with an internal lithium cell which can only be accessed by a qualified technician.

#### Battery

Move/2500 is fitted with battery specially designed for this terminal.

- Only use the appropriate chargers and batteries listed in the Ingenico's catalogue.
- Do not short-circuit the battery.
- Do not attempt to open the battery container.
- Used batteries must be disposed of at the appropriated sites.



### WARNING

There is a risk of explosion if the battery is incorrectly replaced or is placed in a fire.

#### Electrical power outlet

The electrical outlet must meet the following criteria:

- Must be installed near the equipment and easily accessible;
- Must meet standards and regulations in the country where used;
- For type A plug, the protection of the installation must be set to 20 A.

## **SAM1/SAM2/SIM1/(SAM3/SIM2) readers compartment**

The trapdoor for battery, SAM1/SAM2/SIM1/ (SAM3/SIM2), readers located underneath the terminal, must be in place during the normal operation of the terminal. See sections «Removal of SAM1/SAM2/SIM, modules» as well as «Connecting the battery».

### **On airplanes**

Your handset must be switched off by removing the battery pack. Remove the battery from the terminal when on an airplane.

Non-compliance with these safety rules may result in legal action and/or a ban on later access to cellular network services.

### **Explosion areas**

Certain regulations restrict the use of radio equipment in chemical plants, fuel depots and any site where blasting is carried out. You are urged to comply with these regulations. The terminal shall be protected by a specially fitted and certified cover enabling use in proximity to a fuel pump.

### **Electronic health appliances**

Your handset is a radio transmitter which may interfere with health appliances, such as hearing aids, pacemaker, hospital equipment, etc. Your doctor or the equipment manufacturer will be able to provide you with appropriate advice.

## **5.2 Security of your terminal**

Your device fulfils current applicable PCI PTS security requirements.

Upon receipt of your terminal you should check for signs of tampering of the equipment. It is strongly advised that these checks are performed regularly after receipt. You should check, for example: that the keypad is firmly in place; that there is no evidence of unusual wires that have been connected to any ports on your terminal or associated equipment, the chip card reader or any other part of your terminal. Such checks would provide warning of any unauthorised modifications to your terminal, and other suspicious behaviour of individuals that have access to your terminal. Your terminal detects any "tampered state". In this state the terminal will repeatedly flash the message "Alert Irruption!" and further use of the terminal will not be possible. If you observe the "Alert Irruption!" message, you should contact the terminal helpdesk immediately.

You are strongly advised to ensure that privileged access to your terminal is only granted to staff that have been independently verified as being trustworthy.

The terminal must never be put in or left at a location where it could be stolen or replaced by another device.




## CAUTION

Positioning of the terminal on check stand must be in such a way to make cardholder PIN (Personal Identification Number) spying infeasible.

Installing device on an adjustable stand must be in such a way that consumers can swivel the terminal sideways and/or tilt it forwards/backwards to a position that makes visual observation of the PIN-entry process difficult.

Positioning of in-store security cameras such way that the PIN-entry keypad is not visible.

**NEVER** ask the customer to divulge their PIN Code. Customers should be advised to ensure that they are not being overlooked when entering their PIN Code.



## 5.3 Fixed installation

If the device is to be used in a situation where it is not possible for the cardholder to pick up and shield their PIN entry themselves, the device may be used without PIN shield, but it must be installed in the following

- a) The device must be angled at 45 or more, so that oversight of the PIN
- b) The device must either be fitted in a swivel stand – so that the customer can position the device in the best angle to prevent oversight – or the device must be fixed in the best possible position to prevent oversight if such a generic position exists in the specific environment to which the device is installed.
- c) The device environment must be accompanied with conspicuous notices and educational material which informs the customer to shield their PIN during PIN entry.
- d) The device must be deployed so that oversight from other customers, either in different payment lanes, or in other areas of the shopping environment, is prevented. This may be achieved through the placement of the lanes and device, so that the customer is automatically positioned between the device keypad and other customers. Alternatively, it may be achieved by the environment in which the device is installed, so that the checkout itself shields the PIN entry process.
- e) The terminal is exclusively made for indoor use.

If the above conditions are not fulfilled, the device with PIN shield must be used.



### CAUTION

Positioning of the terminal on check stand must be in such a way to make cardholder PIN (Personal Identification Number) spying infeasible.

Installing device on an adjustable stand must be in such a way that consumers can swivel the terminal sideways and/or tilt it forwards/backwards to a position that makes visual observation of the PIN-entry process difficult.

Positioning of in-store security cameras such that the PIN-entry keypad is not visible.

NEVER ask the customer to divulge their PIN Code.

Customers should be advised to ensure that they are not being overlooked when entering their PIN Code.

## 6. Standards

### 6.1 Environment (WEEE, Batteries and Packaging)

This product is labeled in accordance with European Directives 2002/96/EC concerning Waste Electrical and Electronic Equipment (WEEE) and 2006/66/EC concerning Batteries and Accumulators. Those provisions are requiring producers and manufacturers to become liable for take-back, treatment and recycling upon end of life of equipment and batteries.



The associated symbol means that WEEE and waste batteries must not be thrown away but collected separately and recycled.

Ingenico ensures that efficient collection and recycling schemes are set-up for WEEE and batteries according to the local regulation of your country. Please contact your retailers for more detailed information about the compliance solution in place for disposing of your old product and used batteries.

Packaging waste must also be collected separately to assure a proper disposal and recycling.

Please note that proper recycling of the electrical and electronic equipment and waste batteries will ensure safety of human health and environment.

### 6.2 FCC/IC Compliance

Model Name

Product : Move/2500 CL/Eth/Mod/3G

FCC ID

FCC ID : XKB-M2500CL3G

IC NUMBER

IC : 2586D-M2500CL3G

- You are cautioned that changes or modifications not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.
- This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct interference by one or more of the following measures :
  - Reorient or relocate the receiving antenna.
  - Increase the separation between the equipment and receiver.
  - Connect the equipment into an outlet on circuit different from that to which the receiver is connected.
  - Consult the dealer or an experienced radio/TV technician for help.
- This device complies with Part 15 of the FCC Rules and Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions :
  - (1) This device may not cause harmful interference, and
  - (2) This device must accept any interference received, including interference that may cause undesired operation.
- Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :
  - (1) l'appareil ne doit pas produire de brouillage, et
  - (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

- Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.
- Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante.
- No changes shall be made to the equipment without the permission of Ingenico as this may void the user's authority to operate the equipment.
- Tout changement apporté à ce terminal non expressément approuvé par Ingenico est susceptible d'annuler le droit de l'utilisateur à se servir de cet équipement.
- This product meets the applicable Innovation, Science and Economic Development Canada technical specifications. The Ringer Equivalence Number (REN) indicates the maximum number of devices allowed to be connected to a telephone interface. The termination of an interface may consist of any combination of devices subject only to the requirement that the sum of the RENs of all the devices not exceed five. REN for this device is 0.1.
- Le présent appareil est conforme aux spécifications techniques applicables d'Innovation, Sciences et Développement économique Canada. L'indice d'équivalence de la sonnerie (IES) sert à indiquer le nombre maximal de dispositifs qui peuvent être raccordés à une interface téléphonique. La terminaison d'une interface peut consister en une combinaison quelconque de dispositifs, à la seule condition que la somme des IES de tous les dispositifs n'excède pas cinq. L'IES pour cet appareil est de 0.1.

## Part 68 of FCC Rules

Model Name

Product : Move/2500 CL/Eth/Mod/3G

US MODEM

US : IEOMM01BM2500

This equipment complies with Part 68 of the FCC rules and the requirements adopted by the ACTA. On the bottom of this equipment is a label that contains, among other information, a product identifier in the format US : AAAEQ##TXXXX. If requested, this number must be provided to the telephone company.

This equipment uses the following USOC jacks : (RJ11C).

A plug and jack used to connect this equipment to the premises wiring and telephone network must comply with the applicable FCC Part 68 rules and requirements adopted by the ACTA. A compliant telephone cord and modular plug is provided with this product. It is designed to be connected to a compatible modular jack that is also compliant. See installation instructions for details.

## 7. Marking

Below, you will find the different symbols used on the product and its power supply.



The CE marking is the manufacturer's declaration that the product meets the requirements of the applicable EC directives. The CE mark is a mandatory conformity marking for certain products sold within the European Economic Area (EEA).



Waste of Electrical and Electronic Equipment (WEEE) symbol indicates that when the end-user wishes to discard this product, it must be sent to separate collection facilities for recovery and recycling. By separating this product from other household-type waste, the volume of waste sent to incinerators or land-fills will be reduced and natural resources will thus be conserved.

 This logo indicates that the product operates with a continuous voltage. This symbol is followed by the ratings (voltage and current for instance)

 Mark indicating a power supply meets the level VI requirements.

 Double insulated or class 2 electrical appliances are products that have been designed in a way so as not to require a safety connection to electrical earth (These products must NOT have a safety connection to Earth).

 Indoor use symbol.

 Phone line symbol

 Power charge symbol

 Ethernet symbol

 USB symbol

**LPS** This marking indicates power supply meets limited power source safety requirements.

The REN is used to determine the number of devices that may be connected to a telephone line. Excessive RENs on a telephone line may result in the devices not ringing in response to an incoming call. In most but not all areas, the sum of RENs should not exceed five (5.0). To be certain of the number of devices that may be connected to a line, as determined by the total RENs, contact the local telephone company.

If this equipment causes harm to the telephone network, the telephone company will notify you in advance that temporary discontinuance of service may be required. If advance notice is not practical, the telephone company will notify the customer as soon as possible.

Also, you will be advised of your right to file a complaint with the FCC if you believe it is necessary.

The telephone company may make changes in its facilities, equipment, operations, or procedures that could affect the operation of this equipment. If this happens, the telephone company will provide advance notice in order for you to make the necessary modifications to maintain uninterrupted service.

If trouble is experienced with this equipment, please contact INGENICO, or your local INGENICO distributor or service center in the U.S.A. for repair and/or warrant information.

If your home has specially wired alarm equipment connected to the telephone line, ensure the installation of this equipment does not disable your alarm equipment. If you have questions about what will disable alarm equipment, consult your telephone company or a qualified installer.

U.S.A service center:  
Ingenico North America  
3025 Windward Plaza, suite 600  
Alpharetta, GA 30005  
**USA**

Tel: +1(678) 456 1200  
Fax: +1 (678) 456 1201  
Email: [info.us@ingenico.com](mailto:info.us@ingenico.com)

## 8. Troubleshooting

The terminal does not turn on

- Check the battery (is it discharged, is it connected?)  
A full discharged battery can take long charging time to recover
- Connect terminal to terminal power supply or put it on powered base

Cards are not read

- Check that the magnetic card is swiped correctly (with magnetic band on terminal side).
- Swipe again the card with the magnetic stripe movement constant and rapid
- Verify that the magnetic strip is not damaged, grooved or cracked
- Make sure you have inserted correctly the smart card into the smart card reader and removed the card only after the transaction is performed.

The ticket is not printed

- Check the presence and proper positioning of the paper roll.  
Possibly adjust the paper roll following the instructions in this manual (section 0 "Installing the paper roll")
- Check the type of paper used (thermal paper must be used)
- Verify thermal paper sensitive side.

# NOTES

# NOTES

“This Document is Copyright © 2022 by INGENICO Group. INGENICO retains full copyright ownership, rights and protection in all material contained in this document. The recipient can receive this document on the condition that he will keep the document confidential and will not use its contents in any form or by any means, except as agreed beforehand, without the prior written permission of INGENICO. Moreover, nobody is authorized to place this document at the disposal of any third party without the prior written permission of INGENICO. If such permission is granted, it will be subject to the condition that the recipient ensures that any other recipient of this document, or information contained therein, is held responsible to INGENICO for the confidentiality of that information.

Care has been taken to ensure that the content of this document is as accurate as possible. INGENICO however declines any responsibility for inaccurate, incomplete or outdated information. The contents of this document may change from time to time without prior notice, and do not create, specify, modify or replace any new or prior contractual obligations agreed upon in writing between INGENICO and the user.

INGENICO is not responsible for any use of this device, which would be non consistent with the present document.

All trademarks used in this document remain the property of their rightful owners.”

## Your contact



[www.ingenico.com](http://www.ingenico.com)

13 rue Pagès, 92150 Suresnes – France / (T) +33 (0)1 58 01 80 00  
Ingenico - SA au capital de 47 656 332 / 317 218 758 RCS Nanterre