

AXIUM DX4000 Hybrid

User Guide



Terminal ready for
visual impaired people

www.ingenico.com

16 Place de L'Iris Tour Cb21 92400 Courbevoie – France

Banks and Acquirers International Holding, SAS / 814 767 216 RCS Nanterre

Contents

1. Introduction	4
2. Presentation	5
2.1 Content of the box	5
2.2 Overview of AXIUM DX4000 Hybrid.....	6
2.3 Key Locations and Functions.....	8
2.4 Touch Panel.....	8
3. Use of the terminal	9
3.1 Power on/Power off the terminal	9
3.2 Reading cards	10
3.3 Usage of Front Camera	11
3.4 USB Type-C.....	12
3.5 Functional battery door	12
4. Installation	17
4.1 Recommendations.....	17
4.2 Installing modules.....	18

4.3 Paper roll	21
4.4 Battery	23
4.5 Visual Impaired (VI) Accessory(optional).....	26
5. Recommendations	26
5.1 Safety.....	26
5.2 Security of your terminal	28
5.3 Fixed installation	29
5.4 Cleaning the terminal	30
5.5 Transport and storage	30
6. Standards.....	31
7. Accessibility.....	36
8. RED-DA.....	36
9. Troubleshooting.....	37

1. Introduction

We hope that you will be fully satisfied with your new AXIUM DX4000 Hybrid terminal.

Read this guide to understand and make the best use of your terminal. It presents you the necessary information about use, installation, maintenance, safety and security recommendations.



WARRANTY/SECURITY

Use only the power supply included with the product to ensure best performance and safety. Maintenance should only be provided by Ingenico authorized technician.

Failure to comply with these instructions will void the manufacturer's responsibility.



This symbol indicates an important warning.



This symbol indicates a piece of advice.

2. Presentation

2.1 Contents of the box

- AXIUM DX4000 Hybrid terminal
- Power adapter
- Battery pack
- Thermal paper roll
- Functional battery door
- A safety guide



WARNING

The power supply unit provided with your equipment is specially designed for INGENICO AXIUM DX4000 Hybrid terminal. Do not use any other power supply and cable. The use of a power supply and cable with apparently similar voltage/current characteristics may damage your terminal.



ADVICE

Keep the package. It must be re-used whenever the terminal is shipped.

2.2 Overview of AXIUM DX4000 Hybrid



1) Contactless landing zone

2) LEDs for Contactless Card

3) Power Key

4) Volume Keys


5) Functional battery cover

6) Magnetic card reader

7) Smart Card reader

8) LCD and touch screen

9) Front Camera



10) Battery compartment

12) Micro SD slot

14) USB Type-C power port

16) Battery slot

11) Double slots with 2 SIM by default.
In option, it can be configured as 2 SAM

13) Speaker

15) SAM card slot by default.
In option configured as SIM card slot


17) Easy Loading Printer

Weight	435g (including battery)
Dimension (L x W x H)	177.6mm x 80mm x 56.8mm
Electrical mains network	100-240VAC/50-60Hz Class II

2.3 Key Locations and Functions

Three physical keys on the left side of the terminal: a power button and two volume keys.

Three capacitive keys at the bottom of the screen: Menu, Home and Back keys.



2.4 Touch Panel

The AXIUM DX4000 Hybrid is equipped with touch panel that allows you capture functions and menus by your finger.

3. Use of the terminal



ADVICE

Before using the terminal, always check if the roll of paper is present.


3.1 Power on/Power off the terminal

Power On Terminal:

- Make sure the terminal battery is correctly installed.
- Press <Power> button for about 1s until the display is turned on.

Power Off Terminal:

- Press and hold <Power> button for more than 2s until the display shows the following menu.
- Press <Power off>.



Terminal restart:

- In the event of abnormal behavior of the terminal, press and hold the power button for 8 seconds to force the terminal to power off.


Screen saver mode:

- To conserve battery power, the screen may be turned off with a short press of the power button. (approximately 0.5 seconds).


3.2 Reading cards

Magnetic stripe card

- The card can be read bi-directionally, with the stripe facing the terminal.
- Use regular movement to ensure a reliable card reading.


**Contactless card**

- Tap the card or mobile device firmly at the active zone location.
- Keep the card close to the reader during the transaction.
- On the front LEDs are displayed to indicate transaction processing.
- After the card reading is completed, the beep will sound once.




Smart card

- Insert the card horizontally with the metal chip facing upward and leave in position until prompted to remove it.


**3.3 Usage of Front Camera**

- The brightness of the mobile phone must be set to the brightest or not less than the 2/3 of the maximum brightness.
- The mobile phone barcode must face the front scanner above the terminal screen and must be kept stationary.
- The screen of the mobile phone must be parallel to the front scanning head.
- The vertical distance between the screen of the mobile phone and the front scanning head should be between 10cm~30 cm; 20 cm as the optimal position.
- The terminal will beep when the barcode has been successful.



3.4 USB Type-C

- There is a USB type-C connector on the bottom side of the terminal.
- The connector manages Host and Slave connections.




WARNING

To prevent possible hearing damage, do not listen at high volume levels for long periods.

3.5 Functional battery door

3.5.1 Functional battery door Introduction




1) USB Type-C power port

2) RJ45 ETH port

3) USB Type-C plug

3.5.2 Interface definition

- RJ45 ETH port



Sequence	RJ45 Signal
1	TX+
2	TX-
3	RX+
4	NC
5	NC
6	RX-
7	NC
8	NC

3.5.3 Functional battery door Features

Functional battery door specifications

Port	USB Type-C power input port RJ45 network port, support 10M/100M USB Type-C port supporting USB 2.0
Power	Power input:5.0V DC 2.0A (Power input should be compatible with LPS)
Weight	Net Weight:35g Gross Weight:55g

Environmental conditions

Environmental conditions for running, storing and delivering the product :

Temperature	Operating	0°C~40°C / 32°F~104°F
	Storage and Delivery	-20°C~70°C / -4°F ~158°F
Humidity	Running	10%~90%
	Storage and Delivery	5%~90% (40°C) / (104°F)
Max Altitude	2000m	

Installing the Functional battery door

- Install the functional battery door to the DX4000 terminal.
- Connect RJ45 cable to connector on the functional battery door to the power adapter.




WARNING

AXIUM DX4000 Hybrid has been designed to be used with PSU and battery connected. Keep the PSU connected to ensure normal use of the functional battery door, ETH function will disable if PSU is disconnected.




ADVICE

USB data communication is not supported through the functional battery door. To connect the DX4000 to a PC, please remove the functional battery door and plug the USB Type-C cable directly into the terminal's USB port.




3.5.4 Installation

Connect Functional battery door with DX4000 Hybrid



Note: Please put the battery door in the correct position, as the picture shown.



Note: Please put the cable to the correct position in the battery compartment, as the picture shown.

3.5.5 Notes

- Prevent the terminal from sun exposure, high temperature, moisture and other mean conditions.
- Cut off the power before cleaning the device and wipe the main body with dry cloth.
- When the following abnormal phenomena occur, stop running the device immediately, cut off the power supply, and report to the service provider as soon as possible:
 - Harsh noise heard during operation.
 - Dust or water found in the machine.
 - Unpleasant smell noticed during operation.

3.5.6 Delivery and Storage

- Avoid rain and snow, sun exposure and mechanical impact.
- The product should be stored in the original box. The box should be at least 15cm away from the floor, at least 50cm from the wall, heat source, cold source, window or air inlet.

4. Installation

4.1 Recommendations

Operating conditions

Ambient temperature*	From -10°C to +50°C (14°F to 122°F)
Max relative humidity	From 10% to 90%, Non-condensing

(*)Excluding battery charging

Battery charging conditions

Ambient temperature	From 0°C to +40°C (32°F to 104°F)
---------------------	-----------------------------------

Storage conditions

Ambient temperature

From -20°C to +70°C (-4°F to 158°F)

Max relative humidity

From 5% to 90%, Non-condensing

4.2 Installing modules

4.2.1 SAM /SIM1/SIM2 or SIM/SAM1/SAM2




WARNING


Switch off the terminal before opening the battery door.

The SAM/SIM connectors are located inside the terminal, in a closed compartment.


- Turn the terminal and remove the battery door.



- SAM and SIM1, SIM2 or SIM and SAM1, SAM2 are identified by the engraved marks on the lower housing.



SAM/SIM1/SIM2



SIM/SAM1/SAM2

- When introducing a SAM/SIM into slot, be sure to put the cut corner as indicated on the picture.
- Close the battery door.



ADVICE

AXIUM DX4000 Hybrid is equipped with a dual SIM slot.

When using two SIM cards, it is recommended to insert the bottom one first, then the top one.

When using only one SIM card, it is recommended to insert SIM1 slot (bottom).



ADVICE

SIM and SAM cards share the same form factor, please do be careful to the SIM card socket position.

4.2.2 MicroSD Memory Card





WARNING

Switch off the terminal before opening the battery door.

MicroSD connector is located inside the terminal, in a closed compartment.

- Turn the terminal and remove the battery door.
- MicroSD is identified by the engraved marks on the lower housing.
- Slide the cover to the end and pull to open it. Insert MicroSD card, push the cover to close and slide it to the top to lock it. Be sure to put the MicroSD card contacts downside and the cut corner as indicated on the figure.
- Close the battery door.



NOTE: The terminal supports MicroSD up to 32GB.

4.3 Paper roll

4.3.1 Main characteristics of INGENICO paper roll

R40 paper roll characteristics	Precisions
Color	White
Width	58mm
Diameter	40mm
Length	About 18 meters

- The thermal paper can be deteriorated by poor storage conditions, so we recommend you avoid:
 - Storage in hot wet places(near air-conditioner, humidity higher than 85%).
 - Exposure to sunlight or ultraviolet for long periods.
 - Contact with organic solvents (solvent type adhesive).
 - Direct contact with materials containing plasticizers (PVC transparent folders or envelopes).
 - Direct contact with diazo papers.
 - Direct contact with water.
 - Rubbing or pressing the paper too strongly.




WARNING

For best product performance, only use heat sensitized paper approved by Ingenico.


Please note that the paper cutter is very sharp. Do not touch it.

4.3.2 Installing paper roll

- Open the paper cover by lifting the catch located at the top of AXIUM DX4000 Hybrid and pull the cover to the rear of the terminal.
- Insert the paper roll in the compartment following the directions shown on the picture below.
- Pull the paper up to the top of terminal, maintain the paper and close the cover.
- Press simultaneously on both upper corners of the paper flap until it clips into position.
- Please note that the paper should be cut off upward.



- Incorrect ways of cutting off the paper.





ADVICE

If you insert a new R40 paper roll, tear off the first length (one complete turn to avoid printing on adhesive footprint).



WARNING

Switch off the terminal prior to installing a paper roll. Use only paper approved by Ingenico.

The use of no-approved paper is likely to damage the printer of your terminal.

4.4 Battery

4.4.1 Charging the battery

- When does the battery need to be charged?
 - For safety reasons, the battery included with the terminal is not fully charged. Please charge the battery before use.
 - When used daily, the terminal charges its battery each time the power adapter is connected. Charging starts automatically.
- How can the battery be charged?

Using the power adapter.

 - Connect the power adapter to the terminal USB type-C connector located on the left side of the terminal.
 - Connect the power adapter to the power supply mains network.
 - Check the charging status on the top of the screen(it means battery charging).



ADVICE

When the device is powered on or restarted, it will perform a battery recalibration that takes a few minutes until the displayed percentage reflects the actual battery level.


4.4.2 Installing the battery



WARNING


Check that the terminal is not connected to the main electric network.
Ensure the terminal is powered off before connecting or disconnecting the battery to avoid damage.

- Turn your terminal and unclip the battery door by pushing the clips as shown with the arrow on the picture.
- Disengage the battery door.
- Take the battery pack included in the box.
- Locate the battery pack connector beside the battery compartment.
- Plug the battery pack connector according to the connector locating system.
- Place the battery pack in its compartment.
- Close the battery door.



4.4.3 Remove the battery



- Disengage the battery door.
- Remove the battery pack from the battery compartment.
- Unplug the battery pack connector.
- Close the battery door.



4.4.4 Handling of Battery Fires and Smoke

- Disconnect and isolate: If the device is charging, immediately unplug the PSU and turn it off. Move the device to an open area, away from flammable materials and people. Never touch smoking or burning equipment with your bare hands. Use insulated tools (such as dry wooden sticks) to avoid electric shock or burns.
- Fire extinguishing: Use a dry powder fire extinguisher or a carbon dioxide fire extinguisher to spray at the smoking area to extinguish the fire. You can also use a large amount of sand to cover the burning equipment.

4.5 Visual Impaired (VI) Accessory (optional)

Install ● slide the accessory onto the terminal from the bottom.	Remove ● slide the accessory down and away from the terminal.
	

5. Recommendations

5.1 Safety

Powering down the AXIUM DX4000 Hybrid

Disconnect the AXIUM DX4000 Hybrid power supply block adapter from the electrical mains network.

Lithium cell

The AXIUM DX4000 Hybrid is fitted with an internal lithium cell which should only be accessed by a qualified technician.

Battery

- Battery is mandatory for printing.
- AXIUM DX4000 Hybrid is fitted with battery specially designed for this terminal.
- Only use the appropriate chargers and batteries listed in the Ingenico's catalogue.
- Do not short-circuit the battery.
- Do not attempt to open the battery container.
- Used batteries must be disposed of at the appropriate sites.
- For long-term storage: recharge the battery at least twice per year to avoid capacity loss and body deformation due to deep discharge. It is recommended to discard unused batteries sitting in stock for 3 years.
- The battery cover is part of the fireproof enclosure. It is necessary to ensure that the battery cover is on the product.

The lifespan of battery depends on

- Features used.
- Number of charge and discharge cycles.
- Use temperature.

Signs that the battery should be replaced

- The battery fuel gauge / percentage meter drops randomly.
- Charging finishes prematurely even though the battery did not accept much power.
- Sudden capacity drops without warning.
- Self-discharge rate soars and is often uneven.
- The battery gets very hot during charging.
- The battery starts bulging.



CAUTION

Risk of explosion battery is replaced by an incorrect type.
Dispose of used batteries according to the instructions.

SAM/ SIM1/SIM2 or SIM/SAM1/SAM2 Readers compartment

- The battery door for battery, SAM /SIM1/SIM2 or SIM/SAM1/SAM2 readers located underneath the terminal, must be in place during the normal operation of the terminal.
- See sections "Installing modules" and "Installing the battery".

Tips for usage environment

- Avoid putting the terminal in direct sunlight, high temperature, moist, dusty or explosive and reduce or eliminate vibration and direct pressure.
- Keep the device and accessories out of reach of children.

On airplanes

- Your terminal must be switched off by removing the battery pack. Remove the battery from the terminal when on an airplane.
- Non-compliance with these safety rules may result in legal action and/or a ban on later access to cellular network services.

Explosion areas

- Some regulations restrict the use of radio equipment in chemical plants, fuel depots and any site where blasting is carried out.
- You are urged to comply with these regulations.
- The terminal shall be protected by a specially fitted and certified cover enabling use in proximity to a fuel pump.

Thunderstorm weather

- According to some relevant reports, the mobile phone electromagnetic wave is good conductor of lightning.
- It is much easier to suffer lightning strikes when the damp atmosphere forms magnetic conductivity, especially in open areas.
- Do not use wireless terminals in thunderstorm weather.

Electronic health appliances

- Your terminal is a radio transmitter which may interfere with health appliances, such as hearing aids, pacemakers, hospital equipment, etc.
- Your doctor or the equipment manufacturer will be able to provide you with appropriate advice.

5.2 Security of your terminal

Your device fulfills current applicable PCI PTS security requirements.

Upon receipt of your terminal, you should check for signs of tampering of the equipment. It is strongly advised that these checks are performed regularly after receipt. You should check, for example: that the keypad is firmly in place; that there is no evidence of unusual wires that have been connected to any ports on your terminal or associated equipment, the chip card reader, or

any other part of your terminal. Such checks would provide warning of any unauthorized modifications to your terminal, and other suspicious behavior of individuals that have access to your terminal. Your terminal detects any "tampered state". In this state the terminal will repeatedly flash the message "Warning Detected" and further use of the terminal will not be possible. If you observe the "Warning Detected" message, you should contact the terminal helpdesk immediately.

You are strongly advised to ensure that privileged access to your terminal is only granted to staff that have been independently verified as being trustworthy. The terminal must never be put in or left at a location where it could be stolen or replaced by another device.

5.3 Fixed installation

If the device is to be used in a situation where it is not possible for the cardholder to pick up and shield their PIN entry themselves, the device may be used, but it must be installed in the following manner:

- The device must be angled at 45 or more, so that oversight of the PIN entry from the repairing the device is not possible.
- The device must either be fitted in a swivel stand – so that the customer can position the device at the best angle to prevent oversight – or the device must be fixed in the best possible position to prevent oversight if such a generic position exists in the specific environment to which the device is installed.
- The device environment must be accompanied by conspicuous notices and educational material which informs the customer to shield their PIN during PIN entry.
- The device must be deployed so that oversight from other customers, either in different payment lanes, or in other areas of the shopping environment, is prevented. This may be achieved through the placement of the lanes and device, so that the customer is automatically positioned between the device keypad and other customers. Alternatively, it may be achieved by the environment in which the device is installed, so that the checkout itself shields the PIN entry process.
- The terminal is exclusively made for indoor use.



ADVICE

Positioning of the terminal on check stand must be in such a way to make cardholder PIN (Personal Identification Number) spying infeasible.

Installing device on an adjustable stand must be in such a way that consumers can swivel the terminal sideways and/or tilt it forwards/backwards to a position that makes visual observation of the PIN-entry process difficult.

Positioning of in-store security cameras such that the PIN- entry keypad is not visible.

NEVER ask the customer to divulge their PIN Code. Customers should be advised to ensure that they are not being overlooked when entering their PIN Code.

5.4 Cleaning the terminal

Good rules for proper cleaning of the terminal are:

- Unplug all wires from the terminal prior to cleaning.
- Apply soapy water or other approved cleaning product to a soft, non-abrasive cloth.
- Cleaning product should be applied to the cleaning cloth and not directly applied or sprayed to the terminal. Failure to follow this step may result in damage to the terminal.
- Do not clean the electrical connections.
- Do not use solvents, detergents or abrasive products: Those materials might damage the plastic or electrical contacts.
- Avoid prolonged exposure of the terminal to the direct rays of the sun.
- Do not put anything other than credit cards into the slot of the smart card reader.

5.5 Transport and storage

When transporting the terminal

- Protect the terminal from snow, rain, and excessive exposure to the sun.
- Transport with care to avoid mechanical impact.

- Do not throw the unit forcibly. Prevent the package from intrusion during transportation to avoid breakage. The product should be stored in the original packaging.
- Do not store in warehouses that also contain harmful gases, or inflammable, explosive, or corrosive chemicals.
- Do not expose to strong mechanical vibrations or strong magnetic fields.
- Packaging should be stored at least 15 cm above the ground and be kept away from heat, cold, windows, or air inlet sources by at least 50cm.
- Follow the specific stored conditions as noted in Section 4 of this document.

6. Standards

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The antennas used for this transmitter must be co-located or operating in conjunction with any other antenna or transmitter.

The country code selection is for non-US model only and is not available to all US model. Per FCC regulation, all Wi-Fi product marketed in US must fixed to US operation channels only.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Specific Absorption Rate (SAR) information

SAR tests are conducted using standard operating positions accepted by the FCC with the device transmitting at its highest certified power level in all tested frequency bands, although the SAR is determined at the highest certified power level, the actual SAR level of the device while operating can be well below the maximum value. Before a new product is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the exposure limit established by the FCC, tests for each device are performed in positions and locations as required by the FCC.

For hand hold and body supported operation, this device has been tested and meets the FCC RF exposure guidelines when used with an accessory designated for this product.

Environment (WEEE, Batteries and packaging)

This product is labeled in accordance with European Directives 2012/19/EU concerning Waste Electrical and Electronic Equipment (WEEE) and 2013/56/EU concerning Batteries and

Accumulators. Those provisions require producers and manufacturers to become liable for take-back, treatment and recycling upon end of life of equipment and batteries.

BATTERIES

If your product contains batteries, they must be disposed of at appropriate collection points.

THE PRODUCT



The cross-out waste bin stuck on the product or its accessories means that the product belongs to the family of electrical and electronic equipment, and waste batteries must not be thrown away but collected separately and recycled.

Please contact your retailers for more detailed information about the compliance solution in place for disposing of your old product and used batteries.

Packaging waste must also be collected separately to ensure proper disposal and recycling.

In this way you can participate in the re-use and upgrading of Electrical and Electronic Equipment Waste, which can influence the environment and human health.

Electrical power supply network

The electrical outlet must meet the following criteria:

- Must be installed near the equipment and easily accessible.
- Do not short-circuit the battery.
- Do not attempt to open the battery container.

The power supply label certification eighteen symbols:



CCC (China Compulsory Certificate) Mark



The Regulatory Compliance Mark (RCM)



International Efficiency Marking Protocol (Energy Star Level 6)



In door use only



"Conformite Europe enne" or CE Mark



Double insulation symbol



5 Years China RoHS symbol



10 Years China RoHS symbol



BSMI(Taiwan)



PSE Mark (Japan)



Recycle in accordance with the waste electronic & electrical equipment directive



Underwriters Laboratories Inc (US Compliance)



Made from recyclable material



Low density version of Polyethylene (LDPE)




Chlorinated Polyethylene (CPE)



Risk of explosion if the battery is incorrectly replaced or is placed in a fire



Dispose of batteries at a hazardous waste collection site or recycling facility



Direct Current

7. Accessibility

The product has been designed and manufactured in accordance with the essential accessibility requirements set out in Directive (EU) 2019/882 of the European Parliament and of the Council of 17 April 2019, in particular:

- The user interface is perceivable, operable, understandable, and robust.
- The device supports use by individuals with sensory, motor, or cognitive impairments.

Accessibility has been assessed and tested according to the following harmonized standard: EN 301 549: "Accessibility requirements for ICT products and services" in accordance with the provisions of the Directive (EU) 2019/882 coordination standards specified in Resolution C (2022) 6456

The assessment remains valid as long as the hardware and software integration – including all relevant applications – continues to comply with the requirements set forth by the applicable accessibility directive.

Any significant modifications to the system architecture, user interface, or compatibility with assistive technologies must be reassessed to ensure ongoing compliance.

Some models may need require an external accessory for audio assistance, please contact Ingenico support for more information (<https://www.ingenico.com>).

This user guide is intended for professional use only. Relevant personnel will receive specialized training prior to operation to ensure a full understanding of the operating procedures, safe usage, and proper functionality of the device.

The product is a Point of sales terminal. The intended use of the terminal is to proceed payment transaction. The end user will not have access all functionalities, he will only have access to the transaction acceptance: it means present card, enter pin and validate/check the payment transaction. For any operational questions, end users may contact on-site professionals for assistance.

Power & Scan buttons for professional use only.

8. RED-DA

The product has been designed and manufactured in accordance with the essential requirements of the RED DA (Radio Equipment Directive Delegated Act), as set out in Commission

Delegated Regulation (EU) 2022/30 of 29 October 2021 supplementing Directive 2014/53/EU of the European Parliament and of the Council with regard to the application of the essential requirements referred to in Article 3(3), points (d), (e) and (f).

- Article 3.3 (d): Network Protection
- Article 3.3 (e): Data and Privacy Protection
- Article 3.3 (f): Fraud Prevention

RED DA aspects have been assessed and tested in accordance with the harmonized standard EN 18031: "Common security requirements for radio equipment", ensuring alignment with the essential cybersecurity requirements of Directive 2014/53/EU. This applies to the relevant categories and classes of radio equipment as specified in Delegated Regulation (EU) 2022/30. The assessment remains valid as long as the hardware and software integration – including all relevant applications – continues to comply with the requirements set forth by the applicable RED DA. Any additional software should follow RED DA requirements to remain EU compliant.

Please contact Ingenico support for more information (<https://www.ingenico.com>).

9. Troubleshooting

Q: The terminal cannot be started.

A: The device may be in a low energy status or an application running on the device may be in a defective state. Please ensure that the device is powered and then reset the device. If this still fails, please contact our customer service department for help.

Q: Printer cannot work.

A: This may be caused by abnormal power supply or incorrect paper installation.

Check the battery status or the terminal power connection. If the remaining battery power is insufficient for a complete printing operation, the printer will not print the paper.

Check the printer roller and see if the paper dust cover is correctly installed.

If the problem still exists, please contact our customer service center.

Q: Transaction Processing Failure.

A: Following reasons are likely to cause transaction failure: damaged magnetic card or smartcard SAM card, damaged card reader, improper operation of card swiping, damaged or unconnected, unconnected phone line, etc.

- Try to use more than one magnetic card to test the transaction, to confirm the failure is not caused by magnetic card.
- Make sure card swiping is operated correctly.
- Manually process the transaction instead of card reader. If manual transaction works, the failure may be caused by magnetic card readers.
- Use more than one smart card to test the transaction, to confirm the failure is not caused by smart card. Make sure the SAM card is correctly inserted into the card slot.

"INGENICO is a trademark of BANKS AND ACQUIRERS INTERNATIONAL HOLDING. This Document is Copyright © 2026 BANKS AND ACQUIRERS INTERNATIONAL HOLDING. BANKS AND ACQUIRERS INTERNATIONAL HOLDING retains full copyright ownership, rights and protection in all material contained in this document. The recipient can receive this document on the condition that he will keep the document confidential and will not use its contents in any form or by any means, except as agreed beforehand, without the prior written permission of BANKS AND ACQUIRERS INTERNATIONAL HOLDING. Moreover, nobody is authorized to place this document at the disposal of any third party without the prior written permission of BANKS AND ACQUIRERS INTERNATIONAL HOLDING. If such permission is granted, it will be subject to the condition that the recipient ensures that any other recipient of this document, or information contained therein, is held responsible to BANKS AND ACQUIRERS INTERNATIONAL HOLDING for the confidentiality of that information. Care has been taken to ensure that the content of this document is as accurate as possible. BANKS AND ACQUIRERS INTERNATIONAL HOLDING however declines any responsibility for inaccurate, incomplete or outdated information. The contents of this document may change from time to time without prior notice, and do not create, specify, modify or replace any new or prior contractual obligations agreed upon in writing between BANKS AND ACQUIRERS INTERNATIONAL HOLDING and the user. BANKS AND ACQUIRERS INTERNATIONAL HOLDING is not responsible for any use of this device, which would be non-consistent with the present document. All trademarks used in this document remain the property of their rightful owners."

www.ingenico.com

16 Place de L'Iris Tour Cb21 92400 Courbevoie – France

Banks and Acquirers International Holding, SAS / 814 767 216 RCS Nanterre